

FHC Shower Door Bottom Guide Assembly 1-7/16" Width

Item No. M6059

Features, Advantages, and Benefits

- For use on sliding (top hung) shower door (tub enclosure) systems
- These shower door bottom guides help keep sliding door panels centered to their respective tracks
- Used with 1/2 in. thick door panels

- Constructed of clear injected molded plastic
- \bullet Guides measure 1-15/32 in wide x 1-7/16 in depth x 5/8 in tall walls and fits glass thicknesses of up to 1/2 in
- Easy snap-in or adhesive installation