



FHC Shower Door Bottom Guide Assembly 1-7/16" Width

Item No. M6059

Features, Advantages, and Benefits

- For use on sliding (top hung) shower door (tub enclosure) systems
- These shower door bottom guides help keep sliding door panels centered to their respective tracks
- Used with 1/2 in. thick door panels

- Constructed of clear injected molded plastic
- Guides measure $1\text{-}15/32$ in wide x $1\text{-}7/16$ in depth x $5/8$ in tall walls and fits glass thicknesses of up to $1/2$ in
- Easy snap-in or adhesive installation